



Wall Mount Patio Cover Installation Instructions

- Lay head ledger on sawhorses.
- Mark bottom of head ledger height on wall and snap a line or follow sighting line.
- Locate studs and transfer to head ledger and pre-drill 1/2" pilot hole in head ledger for bolt.
- Load hidden track with hex-head bolts.
- Install rafter brackets exactly per layout provided on CAD drawing (Use 3/8" socket with extension and ratchet to install).
- Face gutter opposite of head ledger and install rafter brackets identical to the head ledger.
- Install end caps.
- Install head ledger with 3/8" lag bolts with large hole-washer for your decorative caps (Use 9/16" wrench or socket to drive).
- Caulk or flash head ledger at this time.
- Calculate post height and cut posts.
- Attach post base plates to post.
- Locate posts position on gutter and mark for drilling with plastic template provided (Use a longer drill bit to avoid drill chuck from rubbing gutter).
- Carefully drill gutter and attach posts with gaskets and screws provided (Use #3 Phillips head driver bit). Tip: extra sawhorses will help in attaching posts to gutter. Place gutter on one set of horses, then place one sawhorse perpendicular to the gutter under each post while you attach.
- If draining water through post, drill hole in gutter now or if a downspout is being used, drill for the downspout adapter.
- Stand up posts and gutter and temporarily brace. Tip: Don't attach post bases to deck until the end of installation.
- Attach your two end rafters through the saddle brackets with the hex-head self-tapping screws provided (Use 5/16" hex-head driver).
- Don't forget your small-hole washer for your decorative cap.
- Attach the rest of your rafters in the same fashion.
- Using a framing square, check cover for square at this time. If not square, shift cover as needed.
- Strip bottom of panel.
- Bring the panel up through the next opening and set in on the rafter.
- Carefully align your panel so it is parallel to the rafter and parallel to the gutter and strip top of panel.
- Install the pressure cap snug and evenly along the rafter with the screws provided (Use #3 Phillips head driver bit).
- Install your beauty cap over the pressure cap.
- Use a 2x2 and a rubber mallet to tap beauty cap onto pressure cap.
- Repeat for the rest of the panels. Tip: It may be necessary to get on the cover in order to finish installing the panels.
- Make a knee board that will span across at least two rafters out of a piece of 3/4" plywood.
- Place 100% cotton towel on the cover and lay the knee board on that.
- Several knee boards make it easier to work.
- Be careful your toes stay on the board or else you may scratch the cover.
- Once your panels are in, place Neoprene gasket under post base before anchoring.
- Plum and anchor your posts with 3/8" lags (Make sure you use large-hole washer for decorative cap). Use 9/16" sockets to attach 3/8" legs.
- If attaching to concrete, use expansion bolts and roto-hammer them into concrete.
- Drill a hole in your post base if you are using it for a downspout or hook-up your downspout.
- Attach all your decorative buttons.
- Install Z-shaped panel stiffener in head ledger.
- You're done! E-mail photos to Kelly@skyvuepatiocover.com